

SMITHS Radiomobile

supplement to
installation instructions

VEHICLE:- TRIUMPH SPORTS (REVISED)

Radio: 50T, 51T, 52T, 500T, 501T, 502T,
40T, 41T, 42T, 400T, 401T, 402T.

Note: Install Mote's in the 50T and 500T
Series as detailed for the corresponding
Model in the Model 40T or 400T Series.

INTRODUCTION.

This supplement refers to Installation Instructions No. F/ST11 - February 1959 and covers a change in Aerial Mounting procedure.

The large hole in the right hand kick panel has been deleted on cars produced as from 6/4/59 and the aerial should be mounted as follows:-

AERIAL MOUNTING.

- (1) Remove closing plate behind right side front wheel (Six $\frac{1}{4}$ " screws).
- (2) Mark off and cut a $\frac{7}{8}$ " diameter hole in wing at position shown in Fig. 1. (F/ST11), and assemble aerial to wing.
- (3) Remove plug in kick panel near aerial and route aerial lead through to control unit location.
- (4) Refit closing plate.

Published by Smiths Radiomobile.

Printed in England.

No. F/ST11/S.

April, 1959.