

ELECTRICAL SYSTEM






Fig. 56



KEY TO FIG. 56

- 1. Generator.
- 2. Ignition Warning Lamp.
- 3. Ignition Coil.
- 4. Distributor.
- 5. Control Box.
- 6. Ignition Switch.
- 7. Ammeter.
- 8. Horns Fuse.
- 9. Horn Relay.
- 10. Horn Push.
- 11. Horns.
- 12. Starter Motor.
- 13. Starter Solenoid.
- 14. Battery.
- 15. Lighting Switch.
- 16. Dip Switch.
- 17. High Beam Indicator Lamp.
- 18. Headlamp High Beam, R.H.
- 19. Headlamp High Beam, L.H.
- 20. Headlamp Dip Beam, R.H.
- 21. Headlamp Dip Beam, L.H.
- 22. Instrument Illumination Rheostat.
- 23. Fuse Unit.
- 24. Stop Lamp Switch
- 26. Stop Lamp, R.H.
- 26. Stop Lamp L.H.

- 27. Ammeter and Gauges Illumination.
- 28. Voltage Stabilizer.
- 29. Heater Blower Motor
- 30. Heater Blower Motor
- 31. Temperature Indicator Gauge.
- 32. Temperature Transmitter.
- 33. Fuel Gauge.
- 34. Tank Unit.
- 35. Speedometer Illumination.
- 36. Tachometer Illumination.
- 37. Reversing Lamp Switch
- 38. Reversing Lamp
- 39. Reversing Lamp.
- 40. Parking Lamp R.H.
- 41. Parking Lamp L.H.
- 42. Direction Indicator R.H. Front.
- 43. Direction Indicator R.H. Front Repeater.
- 44. Direction Indicator R.H. Rear.
- 45. Flasher Unit.
- 46. Direction Indicator Switch.
- 47. Direction Indicator L.H. Front.
- 48. Direction Indicator L.H. Front Repeater.
- 49. Direction Indicator L.H. Rear.

} Optional
extra

} Optional
extra

- 50. Flasher Warning Lamp.
- 51. Windshield Wiper Motor.
- 52. Windshield Wiper Motor Switch.
- 53. Plate Illumination Lamp L.H.
- 54. Tail Lamp L.H.
- 55. Plate Illumination Lamp R.H.
- 56. Tail Lamp R.H.

FRANCE ONLY

- A1. Fuse.
- A2. Horn Relay.
- B1. Relay.
- B2. Solenoid.
- B3. Column Control.
- B4. Transmission Switches.
- A4. Switch.
- A5. Horn low note.

} Overdrive
Optional
Extras

CABLE COLOUR CODE

- B.** Black.
- U.** Blue.
- N.** Brown.
- G.** Green.
- K.** Pink.
- P.** Purple.
- R.** Red.
- S.** Slate.
- W.** White.
- Y.** Yellow.
- D.** Dark.
- L.** Light.
- M.** Medium.